### EYE SPLICE 16-STRAND CLASS I



Class I 16-strand ropes are made from any or all of the following fibers: olefin, polyester, or nylon.

The eye splice is used to place a permanent loop in the end of a rope, generally for attachment purposes to a fixed point. An eye is also used to form the rope around a thimble, which is used to protect the rope, especially when it is to be attached to a shackle, chain or wire rope.

Additional rope needed for splice: 28: plus length of eye.

**TIP:** For this rope awire fid is easier to use than a tubular fid.



#### MEASUREMENTS


Measure 28-inches from end of rope and make Mark A.

Measure 22-inches down from Mark B and make Mark C.

Tie a knot in body of the rope about 11-inches down from Mark D.

**1B** Form desired size of eye and make Mark B opposite Mark A.

Measure 11-inches down from Mark C and make Mark D.




# STEP

#### MARKING COVER TAPER

From Mark A count 5 strand pairs toward the end of rope and mark the 5th pair (left and right strands).


Continue counting down 5 pairs and marking the 5th pair until a total of 5 strand pairs are marked.






#### **CORE REMOVAL**

Carefully open up the braid at Mark C and pull out the core yarns from the end of the rope back to Mark C.





#### TAPERING END OF ROPE

**4A** Pull out marked strand pairs from braid. Do not cut.

Tape end of cover tail and attach fid to tapered end of rope.

Page 1 of 3



### EYE SPLICE 16-STRAND CLASS I




#### PERFORMING SPLICE

**5A** Insert fid into rope at Mark B and out at Mark D.

Pull tail through body of rope from B to D.

As each marked strand pair is about to be buried in the rope at Mark B, carefully cut each strand in the marked pair.

**5D** Continue to pull the tail end of the rope through until Mark A and Mark B coincide.






#### MARKING TAILS

Smooth rope from eye back to Mark D to remove all slack in the braid.

Smooth rope from knot to Mark C to bury as much of the core yarns as possible.

Mark both cover tail and core yarns where they exit from the body of the rope.



Page 2 of 3


# sanson

### EYE SPLICE 16-STRAND CLASS I

# STEP

#### **FINAL TAPER**

- Pull buried tail and cover yarns out of rope at their respective exit points until about 13-inches are exposed. This is the distance that the tail and core yarns overlap in the splice.
- **7B** Cut both cover tail and core yarns where they were marked in step 6C above.
- Taper both cover tail and core yarns from the ends back about 6.5-inches. This taper provides a smooth transition from the buried tail of the splice to the core yarns extending down the remainder of the rope.
- Bury the exposed ends by alternately smoothing the rope from the eye down and from the knot up.



# 8

#### FINISHING THE SPLICE

- Secure knot firmly in place and pull sharply on eye to make sure all slack is removed from splice area and cover and core tails are seated properly.
- Apply whipping to base of eye for a distance of about 1-inch or 2 rope diameters.

