


# Silky FORESTER 3000·4500

2015.05.11



Ref.No.	Part No.	Part Name
1	274-38	Blade 380mm, Forester
2	273-00-42	Blade Cover, Forester (New)
3	273-01	Plastic Insert, Forester
4	272-00-51	Blade Fixing Pipe (metal), Zubat
5	102-04-46	Screw (black, metal)
6	102-04-47	Nut (black, metal)
7	110-04-36	Washer, Accel
8	272-04-32	Bolt, Zubat pole saw
9	272-04-05	Stopper Button Spring, Longboy, Zubat
10	365-04-38	Stopper Button, Longboy
11	370-04-77	Spring Fixing Bolt, Longboy
12A	273-04-04	Clamp Housing (S), Forester
12B	273-04-05	Clamp Housing (L), Forester
13	234-04-06	Spacer, Zubat, Longboy
14	177-04-74	Shaking Proof, Lever (NEW)
15A	177-04-78	Rod Pin, Zubat, Longboy
15B	177-04-84	Rod Pin, Hayauchi, Longboy

Ref. No.	Part No.	Part Name
16A	273-02	Clamp Housing (S) ass'y, Forester
16B	273-03	Clamp Housing (L) ass'y, Forester
17	273-04-02	Rubber Sleeve, Forester
18	273-04-03	Rubber Sole, Forester
19	273-04-01	Rubber Grip Tape, Forester
20A	273-00-22	Pole (S), Forester 3000
	273-00-26	Pole (S), Forester 4500
20B	273-00-23	Pole (M), Forester 3000
	273-00-27	Pole (M), Forester 4500
20C	273-00-12	Pole (L), Forester 3000
	273-00-14	Pole (L), Forester 4500