


BIGshot™ INSTRUCTIONS


WARNING:

The Big Shot firing pouch and elastic straps must be turned AWAY from operator, facing the intended target (left). The Big Shot head can only be safely used with inspected and undamaged Jameson brand utility grade, fiberglass extension poles. DO NOT attempt to use this product on a wooden stick. The operator must wear proper safety equipment including helmet and glasses.




1. Install Big Shot head

into the (female) end of a Jameson fiberglass extension pole. Secure by aligning the two holes and fully engaging the spring loaded pin.




LOCK THIS PIN!




2. Prepare line

by flaking it out on a tarp, into a bucket or bag that is positioned between yourself and the target.



3. Attach line to the ring

of the weighted shot bag (shown with clove hitch with slip).




4. Evaluate target zone

for unexpected or unaware hazards. If there are people or valuable property in the immediate area DO NOT FIRE until they are relocated a safe distance away from the area. Before firing, provide a loud audible warning by either voice or whistle.



5. Lay weight

into pouch as illustrated below and grasp trigger loop with index and middle finger. With your head on one side of the pole and firing pouch on the opposite, pull the firing pouch down the shaft of the pole while changing from a standing position to down on one knee. Aim and release pouch.



HELPFUL THROWLINE TIP: If the target is not obtained, allow the weight to return to the ground, untie it and retrieve the line alone. Attempting to pull the weighted bag back over a branch can result in entanglement or injury from the bag falling back onto your head.

Distributed by:



800-525-8873 SherrillTree.com

Copyright 2007 by Sherrill, Inc.